


Software



NEware End-User Management Software

► Features

- Live system monitoring (view system, zone status, and troubles) without interrupting central station communication or system operation
- Views and monitors live streams of up to 4 HD77 cameras connected to an EVOHD control panel
- Arm / Disarm, bypass zones
- Program access codes and settings of all users in an EVO192 and EVOHD system
- Search, sort and filter saved system events
- Generates and prints customized reports
- Supports internet (TCP / IP) communication (requires an IP Internet Module or PCS Module)
- On-site (local) uploading and downloading at 38.4k baud (EVO) using a 307USB Direct Connect Interface (60m / 200 ft) or a CV4USB Converter (300m / 1000 ft)
- Remote or local upload and download programming via an IP Internet Module or PCS Module
- Supports several languages simultaneously

► System Requirements

Windows XP®, Vista® (32 or 64-bit), Windows 7® (32 or 64-bit)

256 MB of RAM (512 MB of RAM suggested)

Pentium® III 800 MHz or higher

150 MB free disk space

For full details on:



Paradox Insight™ App

Self-Monitoring Application

Refer to page 04



BabyWare PC Software

► Features

- Upload / download via GPRS, IP, landline, or direct connect via 307USB / CV4USB
- User friendly layout and operation
- Easy monitoring and site management tools
- Zone Test Mode: Tests for zone connectivity and operation
- Powerful and fast sort, search and print capability
- Data backup and powerful undo and recycle bin features
- Built-in translation tool

► System Requirements

Microsoft® Windows® / Vista / XP / 2000

512 MB of RAM (1 GB Recommended)

Intel® Pentium® 4, 1.4 GHz processor or faster

150 MB of available hard-disk space for installation (additional 150 MB recommended for multi-accounts and events)